



*Batwater Slough 2019*

# Re-visiting Monitoring Protocols For Wetland Restoration

LCEP Science Work Group  
Meeting, Dec 18, 2019

Sarah Kidd,  
Sneha Rao Manohar



# Refining/Updating monitoring protocols for action effectiveness

Science Work Group Meeting

September 25, 2018

Sarah Kidd, Matthew Schwartz, and Grace Brennan



**Purpose: Continue to the discussion of updating and adding to the original 2009 monitoring protocols.**

**Providing technical recommendations for monitoring the following parameters:**

- **Soil Conditions - LCEP**
- **Sediment Accretion and Erosion –LCEP**
- **Channel Cross-Sections - CLT**
- **Water Surface Elevation & Temp - LCEP**

NOAA Technical Memorandum NMFS-NWFSC-97



**Protocols for Monitoring  
Habitat Restoration Projects  
in the Lower Columbia River  
and Estuary**

February 2009

**Future Discussions: Fish & Macroinvertebrate Monitoring,  
UAV Data Collection, Data Management and Analysis**

# Refining/updating monitoring protocols for action effectiveness

Science Work Group Meeting

September 25, 2018

Sarah Kidd, Matthew Schwartz, and Grace Brennan



## Best Practices – A Quick Guide to Water Surface Elevation and Temperature Data Collection

Prepared by Sarah Kidd, Matthew Schwartz, and Grace Brennan  
Lower Columbia Estuary Partnership  
October 2018



Purpose: Continue to the discussion of updating and adding to the original 2009 monitoring protocols.

October 2018 we published updates to the WSE and Temp Protocols

You can download them here <https://bit.ly/2LYGm6w>

*Best Practices - Quick Guide: Water Surface Elevation and Temperature Data Collection*

### Table of Contents

1. Purpose .....	3
2. Choosing Data Logger Locations .....	3
3. Pre-Deployment Data Logger QA/QC .....	4
Water Surface Elevation and Temp QA/QC .....	4
QA/QC Worksheet 1 .....	6
QA/QC Worksheet 2 .....	7
4. Deployment and Retrieval Protocols .....	7
5. Deployment Installation .....	9
Measurements to make when installing and retrieving the data logger using the standard set up (see Figures 1-3): .....	9
6. Measurements and Calculating Elevation .....	12
7. Post-processing and Analysis .....	13
8. Helpful Resources .....	17

### Table of Figures

Figure 1: Standard data logger installation set up for tidal wetland channels .....	10
Figure 2: Measurements when data logger housing is below placement post .....	11
Figure 3: Measurements when data logger housing is above placement post .....	11
Figure 4: HOBO Water Surface Elevation Data Logger, location of sensor .....	12
Figure 5: Hoboware pop-up for opening a data logger file .....	14
Figure 6: Barometric compensation assistant .....	15
Figure 7: Error in data caused by a sensor freezing during deployment .....	16



Wallooskee Wetland 2015

# Soil Monitoring




# Why Monitor Soil

**Soil is a critical component of any ecosystem**

- In wetlands the biogeochemistry of the soil drives many wetland functions such as nutrient retention, seed germination, and plant growth**

**Wetland Restoration (reintroduction of flooding or shift in flooding regime) dramatically alters soil conditions, creating the template for which new wetland plant communities will grow and develop overtime.**

A close-up photograph of soil with a ruler and a green plant stem. The ruler is white with black markings and the word 'LUMICOLOR 6' is printed on it. The soil is dark brown and appears moist. A green plant stem is visible, partially buried in the soil. The ruler is placed vertically, showing measurements in centimeters and millimeters. The plant stem is positioned near the 10 cm mark on the ruler.

## Why Monitor Soil



**Monitoring Soil Conditions Pre and Post Restoration can provide information on why or why not the plant communities are recovering as expected.**

*Quick Resources for Tidal Wetland Soil Monitoring:  
Zedler 2000, Seybold et al. 2002, Kidd 2017*

# What to Monitor

## In the Field

- **Soil Texture**
  - **Sandy, Silty, Loam** – these textures can influence conditions and plant growth
  - **Soil Color** is an indicator of hydric soil conditions (**Gleying and Mottling**)



# What to Monitor

## In the Field


- pH  
→ Is the soil too acidic or basic?
- Salinity/Conductivity  
→ How has soil salinity changed?

### Nutrient Bioavailability

Acidic Soil  
(low pH)

"Just Right"

Alkaline Soil  
(high pH)



# What to Monitor

## In the Field

Hydric soil (develops with lack of O<sub>2</sub>) – Rate of O<sub>2</sub> diffusion into soil dramatically reduced when soil is saturated with water. **This can be measured as soil ORP – Oxygen Reduction Potential.**




*This is an indicator of duration and timing of soil flooding – and these conditions can determine which plant communities can germinate and grow*

# In the Field

## Soil ORP – Oxygen Reduction Potential

What to Monitor

*Multiple soil and hydrologic metrics inform plant community development, however preliminary tidal wetland field data indicate a clear zonation based on observed soil ORP conditions*




Restored Fresh Tidal Wetland Zonation

# In the Field

## Soil ORP – Oxygen Reduction Potential

What to Monitor


*Multiple soil and hydrologic metrics inform plant community development, however preliminary tidal wetland field data indicate a clear zonation based on observed soil ORP conditions*



# Field Equipment

- Extech ORP Meter
- Extech Salinity, pH meter
- For sites with more saline influence – a refractometer can be used (Pore-water soil salinity)





## What to Monitor

### In the Lab

- **Bulk Density, Organic Matter Composition, Carbon, Nutrients (N, P etc.), and Mineral Composition, etc.**
- **Baseline Reference Conditions have been Established in Reference Wetlands through the EMP program (EMP 2019)**

*These are also important soil metrics that should be considered when monitoring restoration outcomes - however they do involve field collection and lab assessment*

# Current Practice



Field	Lab
EMP Reference Sites & Level 2 AEMR Sites, Conducted Along Side of Vegetation Monitoring	EMP Reference Sites, Soil Collected with Biomass and Vegetation Samples
pH	Bulk Density
Salinity/Conductivity	Organic Matter
ORP	Carbon, Nitrogen, Phosphorus Content
<i>Texture/Color (to be added)</i>	Texture


# Next Steps & Understanding Results

## In the Office

- Publish/Share Protocols
- Take all collected data and develop thresholds associated with plant community development and recovery
- Use data to help explain why or why not wetland plant community recovery is occurring across sites

Native vs. Non-native Species  
Soil ORP  
5 Site Summary

PRELIMINARY FIELD  
OBSERVATIONS



Utilize soil and plant community data to set-up **Blue Carbon Study** – looking at methane and carbon emissions and storage across LCE wetlands.

Sediment Accretion and  
Erosion Monitoring



# Why Monitor Sediment Accretion/Erosion


**Monitoring sediment accretion/erosion conditions pre and post restoration can:**

- **Provide information on how natural sediment dynamics have been restored to a wetland**
- **Help us understand if a site is keeping up with potential sea level rise conditions**



## Why Monitor Sediment Accretion/Erosion

- Existing data has shown that sediment accretion/erosion can be very dynamic.
- This variability indicates that to get generalizable results we need to increase the amount of data collected.




**Figure 3.3.** Annual accretion rate by elevation for three restoration sites.

Why  
Monitor  
Sediment  
Accretion/Erosion

What influences Sediment Accretion/Elevation  
within a Tidal Wetland Site?



A person wearing a grey wading suit is kneeling in a muddy, shallow wetland area, likely sampling sediment. The background shows a body of water and some vegetation.

## Why Monitor Sediment Accretion/Erosion

### What influences Sediment Accretion/Elevation within a Tidal Wetland Site?


- **Topography**
  - Elevation and Distance from Main Channel
- **Hydrology**
  - Frequency, Depth, Velocity of Flooding
- **Vegetation and Soil**
  - Vegetation Type, Cover, Soil Exposed, Soil Texture, Soil Compaction
- **Disturbance**
  - Storm Activity/High Flow, Animal Activity (Cattle, Elk, Deer, Rodents, Carp) – Exposing Soil etc.,
- **Availability of sediment flowing in/out of site**

# Best Practices Sediment Bench Monitoring

## Number and Distribution of Sediment Accretion/Erosion Benches Across a Site


- **Multiple Sed Benches Located Across Several Elevation Gradients in Areas of Interest**
- **Pre-restoration use restoration plans to install where possible, post-restoration placement in areas heavily graded**

### Suggested Ideal Minimum Distribution of Sed Benches




Best Practices  
Sediment  
Bench  
Monitoring

**How to install**



# Best Practices Sediment Bench Monitoring

## How to install



### Materials:

- 1 inch conduit pipe, 5 ft+ long
- Level: 120+ cm long
- 2 Meter Sticks or Bendy Rulers
- Compass
- Mallet
- Design Plans
- RTK/GPS Unit



# Best Practices Sediment Bench Monitoring

**How to Monitor, Data Collection –  
What do I record?**



# Best Practices Sediment Bench Monitoring

## How to Monitor, Data Collection – What do I record?

- Bring your notes from the last time you came out to measure the sed bench
- Bring a buddy
- Accuracy and Precision comparable to SET if care is taken (Nolte et al. 2012)










# Best Practices Sediment Bench Monitoring

- Always measure from the ground to the **top of the PVC – bottom of level** (NOT to an arbitrarily place on the level etc).

## How to Monitor, Data Collection – What do I record?



North Pin:

South Pin:

N	E	S	W	10	20	30	40	50	60	70	80	90	100	N	E	S	W







## Recommendations to Start Collecting Additional Data


- Install Multiple Sed Benches Across an Elevation Gradient
- RTK Sed Bench PVC Elevations
- Note Vegetation Cover of Dominant Species
- Monitor Field Soil Parameters at Sed Bench
- Take Photo Point of Sediment Bench and Surrounding Area



# Other Methods

# Other methods for monitoring sediment accretion and erosion:

- SET tables
- Marker horizons
- Sediment Plates
- UAV – Surface Monitoring



National Park Service  
U.S. Department of the Interior

Natural Resource Stewardship and Science

### The Surface Elevation Table and Marker Horizon Technique

*A Protocol for Monitoring Wetland Elevation Dynamics*

Natural Resource Report NPS/NCBN/NRR—2015/1078

Basic Overview Found Here:  
<http://www.tidmarshmonitoring.net/>

### Measuring sedimentation in tidal marshes: a review on methods and their applicability in biogeomorphological studies

S. Nolte · E. C. Koppenaal · P. Esselink · K. S. Dijkema · M. Schuerch · A. V. De Groot · J. P. Bakker · S. Temmerman

Received: 24 October 2012 / Revised: 21 December 2012 / Accepted: 18 January 2013  
© Springer Science+Business Media Dordrecht 2013


**Abstract** It is increasingly recognised that interactions between geomorphological and biotic processes control the functioning of many ecosystem types as described e.g. by the ecological theory of ecosystem engineering. Consequently, the need for specific bio-geomorphological research methods is growing recently. Much research on bio-geomorphological processes is done in coastal marshes. These areas provide clear examples of ecosystem engineering as well as other bio-geomorphological processes: Marsh vegetation slows down tidal currents and hence stimulates the process of sedimentation, while vice versa, the sedimentation controls ecological processes like vegetation succession. This review is meant to give insights in the various

available methods to measure sedimentation, with special attention to their suitability to quantify bio-geomorphological interactions. The choice of method used to measure sedimentation is important to obtain the correct parameters to understand the biogeomorphology of tidal salt marshes. This review, therefore, aims to be a tool for decision making regarding the processes to be measured and the methods to be used. We subdivide the methods into those measuring suspended sediment concentration (A), sediment deposition (B), accretion (C) and surface-elevation change (D). With this review, we would like to further encourage interdisciplinary studies in the fields of ecology and geomorphology.

**Keywords** Accretion · Elevation change · Estuary · Salt marsh · Sediment deposition · Suspended sediment

Detailed Review of Methods – Nolte et al. 2012  
<http://www.vliz.be/imisdocs/publications/242783.pdf>

# Transect #8 Channel Cross Section 2014 - 2018



Updates on Protocols for  
Measuring Channel Cross  
Sections

*Jeff Malone and  
Mitch Attig  
Columbia Land Trust*



Troubleshooting errors in water surface elevation and Temperature  
Data

# Overview

## Best Practices – A Quick Guide to Water Surface Elevation and Temperature Data Collection

Prepared by Sarah Kidd, Matthew Schwartz, and Grace Brennan  
Lower Columbia Estuary Partnership  
October 2018



# Refining/updating monitoring protocols for action effectiveness

Science Work Group Meeting

September 25, 2018

Sarah Kidd, Matthew Schwartz, and Grace Brennan



## Table of Contents

1. Purpose .....	3
2. Choosing Data Logger Locations .....	3
3. Pre-Deployment Data Logger QA/QC .....	4
Water Surface Elevation and Temp QA/QC .....	4
QA/QC Worksheet 1 .....	6
QA/QC Worksheet 2 .....	7
4. Deployment and Retrieval Protocols .....	7
5. Deployment Installation .....	9
Measurements to make when installing and retrieving the data logger using the standard set up (see Figures 1-3): .....	9
6. Measurements and Calculating Elevation .....	12
7. Post-processing and Analysis .....	13
8. Helpful Resources .....	17

## Table of Figures

Figure 1: Standard data logger installation set up for tidal wetland channels .....	10
Figure 2: Measurements when data logger housing is below placement post .....	11
Figure 3: Measurements when data logger housing is above placement post .....	11
Figure 4: HOBO Water Surface Elevation Data Logger, location of sensor .....	12
Figure 5: Hoboware pop-up for opening a data logger file. ....	14
Figure 6: Barometric compensation assistant .....	15
Figure 7: Error in data caused by a sensor freezing during deployment .....	16




What are the  
problems?


# Are these data any good? – Calibration Errors

## 0° C Bath:


- ❖ Use a waterproof pump for best mixing
- ❖ Lay WSE sensors down flat, measure sensor depth
- ❖ Sink temperature loggers with weights
- ❖ Wait at least 10 – 20 minutes for loggers to stabilize
- ❖ Measure Temperature of the bath for at least 75 – 90 minutes to get 10 consecutive minutes of the same temperature



# Prior to using water pump



# After using water pump




# Are these data any good? – Data transfer Errors

## ❖ Failing Loggers

- Temperature shocks
- Biofouling
- False fails

## ❖ Incorrect dates and times on files transferred onto the Shuttle



Time, GMT-07:00	Abs Pres, kPa	Temp, °C
01/09/30 09:00:00 AM	104.773	21.951
01/09/30 09:30:00 AM	104.816	19.377
01/09/30 10:00:00 AM	104.808	19.758
01/09/30 10:30:00 AM	104.798	20.043
01/09/30 11:00:00 AM	104.788	20.329
01/09/30 11:30:00 AM	104.776	20.519
01/09/30 12:00:00 PM	104.745	20.519
01/09/30 12:30:00 PM	104.744	20.424
01/09/30 01:00:00 PM	104.742	20.329
01/09/30 01:30:00 PM	104.738	20.138
01/09/30 02:00:00 PM	104.735	19.948
01/09/30 02:30:00 PM	104.745	19.662
01/09/30 03:00:00 PM	104.741	19.472

# So you got the data

## Water depth above sensor = $D - ((A+B2)-C)$

- Calculating movement of data logger housing during deployment
  - Compare measurements A, B1, B2 and the RTK elevations pre and post deployment, if measurements are significantly different then the data logger housing has shifted and the WSE data may need to be corrected or not usable. Data correction can be done if the precise timing of data logger housing movement can be identified in the hydrologic data and then the new data logger elevation (collected upon retrieval) applied to all data after the shift occurred (See example Figure 5).

## 7. Post-processing and Analysis


Once the data logger has been retrieved from the site and post-deployment water depth measurements have been made (See 4.6) the data can be processed and used to evaluate the conditions on the site. Below are some tips for processing the data in HOBOWare:

### 1. Understanding GMT and Correcting for Daylight Savings


It is best practice to always be aware of which time zone the data logger is collecting in. HOBOWare does not automatically correct for daylight savings. Additionally, the data logger will be launched in whichever time zone your computer clock is in at the time of deployment unless it is adjusted manually. This means if you deploy your data logger in the summer (Daylight Savings Time) and then retrieve your data logger in the winter (Standard Time) your data will be read out in Daylight Savings Time, all time stamps after the fall time boundary (such as November 4 at 2 am) will be an hour off (one hour behind) because HOBOWare does not adjust for shifts between Daylight Savings and Standard Time. This adjustment will need to be done manually in Excel, once exported from HOBOWare. Correcting data for the end or beginning of daylight savings time can cause issues with time series data analysis because it involves deleting or duplicating a date and time when the data crosses a time boundary. Specifically, when daylight saving times begins clocks are moved forward one hour, meaning the 2 am date time on that day is deleted, while when daylight savings time ends the clocks go back one hour, meaning the 2 am time stamp is repeated. To avoid issues with duplicate and deleted time stamps data should be collected and stored in Standard Time, in the Pacific Time Zone this is GMT-8.

It is particularly important to understand how these shifts between daylight savings ending and beginning impact your date and time stamps when trying to compare your reference water levels and temperatures collected to your data logger data. For example if you are collecting all your data in Standard Time (i.e. GMT-8) you will need to make a small adjustment to your reference measurement date and time stamps collected during daylight savings time (i.e. Mar - Nov, see an annual daylight savings table for exact dates) so that the reference measurement time and dates match the loggers time and dates. To shift a daylight savings time stamp (i.e. GMT-7) to a standard time stamp (i.e. GMT-8) you only need to add one hour.


Lastly, understanding the time zone your data is collected in is critical for comparing time series data sets such as multiple loggers to one another or to a gage station, and when correcting your data with barometric data. It is essential to make sure all data sets are in the same time zone for meaningful analyses to be conducted.



# After applying Barometric compensation assistant



# Data Processing Errors: Data Gaps



# Data Processing Errors: Due to Freezing temperatures




Figure 7. Error in data caused by a sensor freezing during deployment.



## Let's reduce those errors!

- ❖ Erase old data and always relaunch Hobo Shuttle
- ❖ QA/QC of loggers during calibrations
- ❖ Ensure loggers are set to the right logging intervals
- ❖ Swap loggers every six months
- ❖ Update hoboWare pro regularly
- ❖ Ensure accurate field measurements: Water level, Temperature and RTK data
- ❖ Check deployed loggers and housing for algal growth and damages

# Next Steps: Data Sharing – Creating a database

The screenshot shows the Microsoft Excel interface with the following data in the spreadsheet:

	A	B	C	D	E	F	G	H
1	Site	Location	Date	Time (GMT -7)	Removed/Downloaded/Placed	Serial Number	Logger Type	Collection Interval
29	MCNA	MCNA3- S channel	12/13/2018	12:05	Placed	20112940	WSE/Temp	30
30	MCNA	MCNA3- S channel	12/13/2018	12:05	Placed	20112567	DO	30
31	MCNA	MCNA3- S channel	6/24/2019	8:40	Removed	20112567	DO	30
32	MCNA	MCNA3- S channel	6/24/2019	8:40	Removed	20112940	WSE/Temp	30
33	MCNA	MCNA3- S channel	6/24/2019	8:50	Placed	20149616	WSE/Temp	30
34	MCNA	MCNA4- S wetland	12/13/2018	12:51	Removed	20358336	WSE/Temp	15
35	MCNA	MCNA4- S wetland	12/13/2018	12:51	Placed	20112939	WSE/Temp	30
36	MCNA	MCNA4- S wetland	12/13/2018	12:51	Placed	20112566	DO	30
37	MCNA	MCNA4- S wetland	6/24/2019	9:16	Removed	20112939	WSE/Temp	30
38	MCNA	MCNA4- S wetland	6/24/2019	9:20	Placed	20112664	WSE/Temp	30
39	MCNA	MCNA4- S wetland	6/24/2019	9:16	Removed	20112566	DO	30
40	MCNA	MCNA5- Crabapple	12/13/2018	14:13	Removed	20149616	WSE/Temp	15
41	MCNA	MCNA5- Crabapple	12/13/2018	14:13	Placed	10810155	WSE/Temp	30
42	MCNA	MCNA5- Crabapple	1/29/2019	12:47	Placed	10330643	DO	30
43	MCNA	MCNA5- Crabapple	6/24/2019	12:23	Removed	10330643	DO	30
44	MCNA	MCNA5- Crabapple	6/24/2019	12:10	Removed	10810155	WSE/Temp	30
45	MCNA	MCNA5- Crabapple	6/24/2019	12:22	Placed	10563696	WSE/Temp	30
46	MCNA	MCNA7- South Bar Scroll	11/9/2018	10:15	Placed	10949783	WSE/Temp	
47	MCNA	MCNA7- South Bar Scroll	6/24/2019	8:13	Removed	10949783	WSE/Temp	

Create a user friendly Data Log!

# Next Steps: Data Sharing – Creating user-friendly DETs

## 5\_Measurement\_DET

Paste atmospherically corrected and elevation corrected water level data into this form for upload into Oncor.

Water_Elevation_Instrument	Instrument_Deployment_Dat	Water_Measurement_Dat	Water_Temperature	Temperature_Sensor_Exposed	Water_Surface_Elevation	Instrument_Measurement_Notes	DB_Access
Hobo_9782045	3/12/2014 15:20	3/12/2014 15:20	11.24		1.4074	WSE Output converted to Meters	
Hobo_9782045	3/12/2014 15:20	3/12/2014 15:30	10.94		1.3473		
Hobo_9782045	3/12/2014 15:20	3/12/2014 15:40	10.94		1.2946		
Hobo_9782045	3/12/2014 15:20	3/12/2014 15:50	10.94		1.2378		
Hobo_9782045	3/12/2014 15:20	3/12/2014 16:00	10.94		1.1851		
Hobo_9782045	3/12/2014 15:20	3/12/2014 16:10	10.94		1.1355		
Hobo_9782045	3/12/2014 15:20	3/12/2014 16:20	10.94		1.0835		
Hobo_9782045	3/12/2014 15:20	3/12/2014 16:30	10.94		1.0314		
Hobo_9782045	3/12/2014 15:20	3/12/2014 16:40	10.94		0.9833		
Hobo_9782045	3/12/2014 15:20	3/12/2014 16:50	10.94		0.9387		
Hobo_9782045	3/12/2014 15:20	3/12/2014 17:00	10.85		0.8965		
Hobo_9782045	3/12/2014 15:20	3/12/2014 17:10	10.85		0.8510		
Hobo_9782045	3/12/2014 15:20	3/12/2014 17:20	10.85		0.8048		
Hobo_9782045	3/12/2014 15:20	3/12/2014 17:30	11.04		0.7645		
Hobo_9782045	3/12/2014 15:20	3/12/2014 17:40	11.04		0.7257		
Hobo_9782045	3/12/2014 15:20	3/12/2014 17:50	11.04		0.6894		
Hobo_9782045	3/12/2014 15:20	3/12/2014 18:00	11.04		0.6516		
Hobo_9782045	3/12/2014 15:20	3/12/2014 18:10	11.04		0.6169		
Hobo_9782045	3/12/2014 15:20	3/12/2014 18:20	11.04		0.5847		
Hobo_9782045	3/12/2014 15:20	3/12/2014 18:30	11.04		0.5530		
Hobo_9782045	3/12/2014 15:20	3/12/2014 18:40	11.04		0.5248		
Hobo_9782045	3/12/2014 15:20	3/12/2014 18:50	11.04		0.4997		
Hobo_9782045	3/12/2014 15:20	3/12/2014 19:00	11.04		0.4765		
Hobo_9782045	3/12/2014 15:20	3/12/2014 19:10	11.04		0.4560		
Hobo_9782045	3/12/2014 15:20	3/12/2014 19:20	11.04		0.4377		
Hobo_9782045	3/12/2014 15:20	3/12/2014 19:30	11.04		0.4225		
Hobo_9782045	3/12/2014 15:20	3/12/2014 19:40	10.94		0.4117		



# References

Continuous Water Level Data Collection and Management Using Onset HOBO® Data Loggers

Natural Resource Report NPS/NCBN/NRR—2017/1370

<https://irma.nps.gov/DataStore/DownloadFile/563851>

Oregon Plan for Salmon and Watersheds, Water Quality Monitoring Guidebook, Temperature Protocols Chapter 6:

<http://docs.streamnetlibrary.org/Protocols/021.pdf>

Washington Department of Ecology Quality Assurance Monitoring Plan: Continuous Monitoring for Oxygen, Temperature, pH, and Conductivity in Statewide Rivers and Streams

<https://fortress.wa.gov/ecy/publications/summarypages/0903122.html>

HOBOWare User's Guide:

<http://www.onsetcomp.com/support/manuals/12730-MANBHW-UG>

HOBOWare Pro Barometric Compensation Assistant User's Guide:

[http://www.onsetcomp.com/files/manual\\_pdfs/Barometric-Compensation-AssistantUsers-Guide-10572.pdf](http://www.onsetcomp.com/files/manual_pdfs/Barometric-Compensation-AssistantUsers-Guide-10572.pdf)

HOBO® U20 Water Level Logger Manual:

[http://www.onsetcomp.com/files/manual\\_pdfs/12315-F-MAN-U20.pdf](http://www.onsetcomp.com/files/manual_pdfs/12315-F-MAN-U20.pdf)

Specifications for HOBO® U20 Water Level Loggers:

<http://www.onsetcomp.com/files/datasheet/Onset%20HOBO%20U20%20Water%20Level%20Data%20Loggers.pdf>

Specifications for HOBO® U20L Water Level Loggers:

<http://www.onsetcomp.com/files/datasheet/Onset-HOBO-U20L-Water-Level-DataLogger-Series.pdf>

US Geological Survey. 2012. Water level continuous standard operating procedures. Unpublished protocols. USGS, Western Ecological Research Center, San Francisco Bay Estuary Field Station, Vallejo, CA.

<http://www.tidalmarshmonitoring.org/monitoring-methods-hydrology.php>

# SWG Discussion

Input on other protocols

Use of remote sensing, e.g., drones for data collection

- Use of drones is specific to monitoring goals and available equipment and expertise of handler, so protocols need to be specific to these items and may not be practical. BUT are there a subset of metrics that we can standardize?
- Is this a topic of discussion for future SWG?

Topics for future SWG:

- Results from 5 years of AEM - what seems to be working, what might need “tweaking”, other lessons to share amongst partners
- Results from @ 20 years of restoration in lower Columbia - what seems to be working, what might need “tweaking”, other lessons to share amongst partners